



CORRECT WAY TO STORE THE SHOCKLOCK™



Incorrect! The Shocklock is upside down and above rear mudguard. In this position the coiled cable can press the rear mudguard against the tire and damage the mudguard and/or tire. Besides, it is untidy and bad form!



Correct! The Shocklock is coiled neatly over the license plate. Nice and tidy!